


# ***GDC Installation and Operation***

**UAS 711-D2**



**General DataComm**



# ***GDC Installation and Operation***

**UAS 711-D2**

# Copyright

©1998 General DataComm, Inc. ALL RIGHTS RESERVED.

This publication and the software it describes contain proprietary and confidential information. No part of this document may be copied, photocopied, reproduced, translated or reduced to any electronic or machine-readable format without prior written permission of General DataComm, Inc. The information in this document is subject to change without notice. General DataComm assumes no responsibility for any damages arising from the use of this document, including but not limited to, lost revenue, lost data, claims by third parties, or other damages.

If you have comments or suggestions concerning this manual, please contact:

Technical Publications Department  
General DataComm, Inc.  
Park Road Extension  
Middlebury, Connecticut USA 06762-1299  
  
Telephone: 1 203 758 1811

# Trademarks

All brand or product names are trademarks or registered trademarks of their respective companies or organizations.

# Revision History

**Table-1**      Revision History

Issue Number	Date	Description of Change
01	Dec '98	First Issue

## Safety Guidelines

- Always use the following guidelines when unsafe conditions exist or when potentially hazardous voltages are present:
- Always use caution and common sense.
- To reduce the risk of electrical shock, do not operate equipment with the cover removed.
- Repairs must be performed by qualified service personnel only.
- Never install telephone jacks in a wet location unless the jack is designed for that location.
- Never touch uninsulated telephone wires or terminals unless the telephone line is disconnected at the network interface.
- Use caution when installing telephone lines and never install telephone wiring during an electrical storm.

## Antistatic Precautions

Electrostatic discharge (ESD) results from the buildup of static electricity and can cause computer components to fail. Electrostatic discharge occurs when a person whose body contains a static buildup touches a computer component.

The equipment may contain static-sensitive devices that are easily damaged and proper handling and grounding is essential. Use ESD precautionary measures when installing parts or cards and keep the parts and cards in antistatic packaging when not in use. If possible, use antistatic floorpads and workbench pads.

When handling components, or when setting switch options, always use an antistatic wrist strap connected to a grounded equipment frame or chassis. *If a wrist strap is not available, periodically touch an unpainted metal surface on the equipment.* Never use a conductive tool, like a screwdriver or a paper clip, to set switches.

## FCC Part 68 Compliance

Connection of data communications equipment to the public telephone network is regulated by FCC Rules and Regulations. This equipment complies with Part 68 of these regulations which require all of the following.

For single or multi-line equipment that connects to the telephone network via a plug and jack, the plug and jack must comply with the FCC Part 68 rules. This device is designed to be connected to the telephone or premises wiring, using a compatible modular jack which is Part 68 compliant. See installation chapter for details.

If the unit causes harm to the telephone network, the telephone company may discontinue your service temporarily and if possible, you will be notified in advance. If advance notice is not practical, you will be notified as soon as possible and will be advised of your right to file a complaint with the FCC. The telephone company may change its communication facilities, equipment, operations and procedures where reasonably required for operation. If so, the telephone company will notify you in writing. All repairs or modifications to the equipment must be performed by General DataComm. Any other repair or modification by a user voids the FCC registration and the warranty.

To connect the UAS 711-D2 to the public telephone network the customer is required to provide the following information:

FCC Registration Number: \_\_\_\_\_

Telephone Company jack type: \_\_\_\_\_.

Facility Interface Codes:

T1 Interface - \_\_\_\_\_

Service Order Code: \_\_\_\_\_

## Industry Canada Notification

The Industry Canada label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operation and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**Caution:** Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

**Notice:** The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

## Electromagnetic Compatibility

This Class A digital apparatus complies with Canadian ICES-003.

## Avis D'industrie Canada

L'étiquette d'Industrie Canada identifie le matériel homologué. Cette étiquette certifie que le matériel est conforme aux normes de protection, d'exploitation et de sécurité des réseaux de télécommunications, comme le prescrivent les documents concernant les exigences techniques relatives au matériel terminal. Le Ministère n'assure toutefois pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit s'assurer qu'il est permis de le raccorder aux installations de l'entreprise locale de télécommunication. Le matériel doit également être installé en suivant une méthode acceptée de raccordement. L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêche pas la dégradation du service dans certaines situations.

Les réparations de matériel homologué doivent être coordonnées par un représentant désigné par le fournisseur. L'entreprise de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur ou à cause de

mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit s'assurer que tous les fils de mise à la terre de la source d'énergie électrique, des lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

**Avertissement:** L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours à un service d'inspection des installations électriques, ou à un électricien, selon le cas.

**Avis:** L'indice d'équivalence de la sonnerie (IES) assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface. La terminaison d'une interface téléphonique peut consister en une combinaison de quelques dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

## La Compatibilité d'Électro-magnétique

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

## Deutschland

*Installations Anweisungen:* Installieren Sie die Telefonleitungen nicht während eines Gewitters. Installieren Sie die Telefonleitungen nicht in einem feuchten Raum, außer die Dose entspricht den Vorschriften für Feuchträume. Berühren Sie unisolierte Telefonleitungen oder Einrichtungen nicht, außer diese sind vom Telefonnetz getrennt. Vorsicht bei der Installierung oder Änderung von Telefonleitungen. *Achtung:* Es gibt keine durch den Benutzer zu wartende Teile im Gerät. Wartung darf nur durch qualifiziertes Personal erfolgen.

## EC Declaration of Conformity

We: General DataComm Limited  
Molly Millars Lane  
Wokingham, Berkshire RG41 2QF, United Kingdom

On behalf of: General DataComm Inc.  
1579 Straits Turnpike  
Middlebury, CT 06762-1299, U.S.A.

The products to which this declaration relates are in conformity with the following relevant harmonized standards, the reference numbers of which have been published in the Official Journal of the European Communities;

### Electromagnetic Compatibility

#### EN55022: 1994

Specification for limits and methods of measurement of radio interference characteristics of information technology equipment.

#### EN 50082-1: 1992

Generic immunity standard Part 1 Residential, Commercial, and Light Industry.

### Safety

#### EN 60950: 1995 A1 through A3

Low Voltage Directive relating to electrical equipment designed for use within certain voltage limits



# Table of Contents

---

<a href="#">Electromagnetic Compatibility</a> .....	vi
<a href="#">Safety</a> .....	vi

## **[Preface](#)**

<a href="#">Organization</a> .....	P-1
<a href="#">Related Publications</a> .....	P-1
<a href="#">Typographical Conventions</a> .....	P-2
<a href="#">Font Styles</a> .....	P-2
<a href="#">Safety Information</a> .....	P-3
<a href="#">Service Support and Training</a> .....	P-4

## **[Chapter 1: System Description](#)**

<a href="#">Overview</a> .....	1-1
<a href="#">Features</a> .....	1-1
<a href="#">Applications</a> .....	1-2
<a href="#">Point-to-Point</a> .....	1-2
<a href="#">Fractional T1 Service</a> .....	1-2
<a href="#">Diagnostics/Network Management</a> .....	1-2
<a href="#">Equipment List</a> .....	1-3

## **[Chapter 2: Installation](#)**

<a href="#">Overview</a> .....	2-1
<a href="#">Unpacking and Handling</a> .....	2-1
<a href="#">Installation</a> .....	2-1
<a href="#">Installation of Shelf</a> .....	2-1
<a href="#">Setting Hard Options on UAS 711-D2</a> .....	2-1
<a href="#">EIA-530 or X.21 Interface Card</a> .....	2-6
<a href="#">Installing the UAS 711-D2</a> .....	2-6
<a href="#">Electrical Lines</a> .....	2-6
<a href="#">Power Line</a> .....	2-6
<a href="#">Communications Line</a> .....	2-7
<a href="#">Preoperational Configuration Setup</a> .....	2-8
<a href="#">Hard</a> .....	2-8
<a href="#">Soft</a> .....	2-8

## Chapter 3: Operation

<a href="#">Overview</a> .....	3-1
<a href="#">Front Panel</a> .....	3-1
<a href="#">Soft Configuration and Control</a> .....	3-2
<a href="#">Terminal Requirements</a> .....	3-2
<a href="#">Startup Procedure</a> .....	3-3
<a href="#">Screen Organization</a> .....	3-3
<a href="#">Operating Procedures</a> .....	3-4
<a href="#">Menu Selection</a> .....	3-4
<a href="#">Field Navigation</a> .....	3-4
<a href="#">Field Editing</a> .....	3-4
<a href="#">Restoring Default Values</a> .....	3-5
<a href="#">Saving Values</a> .....	3-5
<a href="#">Quitting Without Saving</a> .....	3-5
<a href="#">Refresh</a> .....	3-5
<a href="#">Main Menu</a> .....	3-5
<a href="#">Diagnostics</a> .....	3-6
<a href="#">Configuration</a> .....	3-6
<a href="#">Maintenance</a> .....	3-6
<a href="#">Diagnostic Menu</a> .....	3-7
<a href="#">HDSL Monitoring</a> .....	3-7
<a href="#">HDSL Status</a> .....	3-9
<a href="#">Cancel Startup</a> .....	3-10
<a href="#">Configuration Menu</a> .....	3-11
<a href="#">Unit Configuration Screen</a> .....	3-12
<a href="#">Interface Configuration Screen</a> .....	3-13
<a href="#">View H/S Configuration</a> .....	3-15
<a href="#">Maintenance Menu</a> .....	3-16
<a href="#">Network Management</a> .....	3-16
<a href="#">MIB Tables</a> .....	3-16

## Chapter 4: Tests

<a href="#">Overview</a> .....	4-1
<a href="#">Troubleshooting</a> .....	4-1
<a href="#">Maintenance Menu</a> .....	4-1
<a href="#">Loopback Testing</a> .....	4-3
<a href="#">Operation</a> .....	4-4
<a href="#">Line Loopback</a> .....	4-4
<a href="#">Remote Digital Loopback</a> .....	4-5

<a href="#">V.54 Remote Loopback</a> .....	4-5
<a href="#">Test Loopbacks - Considerations</a> .....	4-6
<a href="#">BER Test</a> .....	4-6
<a href="#">Testing Method</a> .....	4-6
<a href="#">Test Configuration Notes</a> .....	4-7
<a href="#">BER Screen Description</a> .....	4-8
<a href="#">Set RTC</a> .....	4-10
<a href="#">Reset Statistic</a> .....	4-11
<a href="#">Operation</a> .....	4-11
<a href="#">HDSL Start-Up</a> .....	4-11
<a href="#">Board Reset</a> .....	4-11

## **[Chapter 5: Application Guide](#)**

<a href="#">Overview</a> .....	5-1
<a href="#">Timing Options</a> .....	5-1
<a href="#">High Channel Data Rate Application</a> .....	5-1
<a href="#">Typical Applications</a> .....	5-2
<a href="#">Single Loop Point-to-Point</a> .....	5-2
<a href="#">Two Loop Point-to-Point</a> .....	5-2
<a href="#">Fractional T1 Service (2 Loop)</a> .....	5-3

## **[Glossary of Terms](#)**

## Table of Contents

# Preface

## Manual Overview

This Preface describes the organization of this manual, typographical conventions used throughout the manual. It is arranged as follows:

<a href="#">Organization</a> .....	P-1
<a href="#">Related Publications</a> .....	P-1
<a href="#">Typographical Conventions</a> .....	P-2
<a href="#">Service Support and Training</a> .....	P-4

## Organization

The intent of this manual is to describe how to install and configure a UAS (Universal Access System) 711-D2 and explains how to monitor and manage this device. This documentation is written for operators and installers, and assumes a working knowledge of data communications equipment. This manual has five chapters and three appendices, organized follows:

- *Chapter 1 - System Description* introduces important concepts and features of the UAS 711-D2.
- *Chapter 2 - Installation* tells you how to install and hard and soft option the UAS 711-D2.
- *Chapter 3 - Operation* describes the front panel of the UAS 711-D2, and also the management sessions you may perform.
- *Chapter 4 - Tests* describes external tests and the Maintenance Menu screens.
- *Chapter 5 - Application Guide* describes timing options and sample applications. Only typical or fundamental applications are given because of the variety of specific customer system choices.

Appendices - *Appendices A, B, and C* cover technical characteristics, HDSL connector pin assignments, and interface signals.

## Related Publications

A complete listing of related manuals is provided below in [Table P-2](#). In addition to the hardware and software manuals, always read the software System Release Notes supplied with your GDC product.

**Table P-2** Related GDC Documents

Applicable Documents	
Publication Name	Publication Number*
Installation and Operation SpectraComm/UAS Shelf and Enclosure	GDC 010R302-REV-IS
Operating and Installation Instructions for SpectraComm Manager Card	GDC 048R303-REV-IS
Installation and Operation GDC SpectraComm 2000 Shelf	GDC 010R358-REV-IS

\* For publications numbers, **REV** is the hardware manual revision (for example, -000, -001, etc.) **VREF** (if listed) is the software revision (for example, -V120 would read, Version 1.2) and corresponds to the most current revision. **IS** is the most current issue of the document (for example, -02 is the second issue). When ordering documentation, request the most current issue.

## Typographical Conventions

### Head\_1st Level

Level 1 Headings introduce major topics and start on a new page. The only exceptions are the Chapter Overview and Manual Overview headings that start immediately after the chapter, preface or appendix title (on the same page as the title).

### Head\_2nd Level

Level 2 Headings introduce subsections of major topics.

### Head\_3rd Level

Level 3 Headings introduce subsections of secondary topics.

### Font Styles

All fonts must be from the basic Adobe Type 1 font set.

Courier font is used to show text output that is displayed on the screen.

**Times bold font** is used when referring to screen names.

**Courier bold font is used to show specific input that you type at the keyboard.**

## Safety Information

The DANGERS, WARNINGS and CAUTIONS that appear throughout this manual are not only preventative measures designed to uphold the safety of both the service engineer and operator, but also enhance equipment reliability.

The definitions and symbols for DANGER, WARNING and CAUTION comply with ANSI Z535.2, American National Standard for Environmental and Facility Safety Signs, and ANSI Z535.4, Product Safety Signs and Labels, issued by the American National Standards Institute.

The following examples show the symbols and definitions of DANGER, WARNING, CAUTION, *Note* and *Important* as they are used in this manual.

---

**Note**

*Indicates a note. It is something you should be particularly aware of; something not readily apparent. A note is typically used as a suggestion.*

---

---

**Important**

*Indicates an emphasized note. It is something you should be particularly aware of; something not readily apparent. Important is typically used to prevent equipment damage.*

---



---

**CAUTION** *Indicates a potentially hazardous situation which, if not avoided, may result in minor to moderate injury. It may also be used to alert against unsafe practices.*

---



---

**WARNING** *Warning indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury.*

---



---

**DANGER** *Danger indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.*

---

## Service Support and Training

**VITAL Network Services**, a General DataComm company, is committed to providing the service support and training needed to install, manage, and maintain your GDC equipment.

GDC's VITAL Network Services provides hands-on training courses through **VITAL Network Services Global Technology Training Services**. Courses range from basic data communications, modems and multiplexers, to complex network and ATM systems. Training courses are available at our centers in the US, UK, France, Singapore and Mexico, as well as at a customer's site.

For more information regarding GDC's VITAL Network Services' service programs, training courses, or for assistance with your support requirements, contact GDC's VITAL Network Services at the address or phone number listed below, or visit our website at: <http://www.vitalnetsvc.com>

### VITAL Network Services World Headquarters

6 Rubber Avenue  
Naugatuck, Connecticut 06770 USA

North America:	1 800 243 1030
	1 888 248 4825
	1 203 729 2461
Training Information:	1 203 729 0271
French Speaking Canada:	1 800 361 2552
North America Fax:	1 203 723 5012
	1 203 729 7611

---

### VITAL Network Services Regional Sales and Service Offices:

#### Europe, Middle East, Africa

VITAL Network Services  
Molly Millars Close  
Molly Millars Lane  
Wokingham, Berkshire RG41 2QF UK

Telephone:	+44 1189 657200
Training:	+44 1189 657240
Fax:	+44 1189 657279

#### Central America, Latin America

VITAL Network Services  
Periferico Sur 4225, Desp. 306  
C.P. 14210, Mexico D.F., Mexico

Telephone:	+52 5 645 2238
Training:	+52 5 645 2238
Fax:	+52 5 645 5976

#### Asia Pacific

VITAL Network Services  
501 Orchard Road 05-05  
Wheelock Place, Singapore 238880

Telephone:	+65 735 2123
Training:	+65 735 2123
Fax:	+65 735 6889

### International Calling Code (+)

When calling from outside the country of origin, use the appropriate International Calling Code where the + symbol is shown.

---



# Chapter 1: System Description

## Overview

The UAS (Universal Access System) 711-D2 is designed to provide a connection between a DTE (Data Termination Equipment) interface and HDSL (High-Bit-Rate-Digital Subscriber Line). The UAS 711-D2 product card operates as either an LTU (Line Terminating Unit) or an NTU (Network Terminating Unit). Mounted in a SpectraComm/UAS Shelf or a SpectraComm 2000 Shelf, it is managed through a front panel supervisory terminal, hard switches, a shelf-resident SCM (SpectraComm Manager) Card, and an associated SNMP (Simple Network Management Protocol) manager. The 711-D2 is offered as a two-HDSL loop device with a bandwidth of Nx64 kbps for N = 1 to 24 and has a maximum data rate of 1536 kbps.


**Note** *The UAS is a family of network managed metallic loop transmission products. A shelf-mounted UAS product card works with a standalone unit located at the far end of the access the loop. Full network management capabilities are achieved using the SCM and its interface to a UNIX-based workstation.*

Part numbers for standard and optional equipment for the 711-D2 are listed in [Table 1-1](#). Technical Characteristics are listed in Appendix A.

## Features

The UAS 711-D2 interfaces with your HDSL system and provides the following features:

- Configurable as either a Line Terminating Unit or Network Terminating Unit.
- Software configurable through front panel supervisory terminal. Hardware configurable via on board jumpers and switches.
- Full Network Management by means of the shelf resident SCM Card and an associated SNMP manager.
- Operates on one or two HDSL loops. Supports Nx64 kbps digital data rates selectable from N = 1 through 12 over one loop, N = 1 through 24 over two loops.
- V.35 DTE interface, or optionally EIA 530 (V.11)/X.21.
- Tx Clock modes for DTE interface include Looped, External, and Internal.
- Internal BER (Bit Error Rate) tester.
- Local Loopback and Remote Digital Loopback capabilities. Supports V.54 inband loopback control.
- Supports V.54 inband loopback control.



## Applications

### Point-to-Point

The 711-D2 has two point-to-point configurations (See [Figure 1-1](#)): one with a bandwidth of Nx64 kbps for N=1 to N=12 (one loop is enabled) and one with a bandwidth of Nx64 kbps for N=1 to N=24 (two loops are enabled).


### Fractional T1 Service

This application provides for Fractional T1 service. Bandwidth is 64 kbps up to 1536 kbps for the 711-D2.

---

**Note** Other applications may be found in Chapter 5 of this manual.

---



**Figure 1-1** Typical UAS 711-D2 Applications

## Diagnostics/Network Management

Diagnostics are used to detect malfunctions in a system or component. Operation and parameters are controlled by switches and jumpers mounted on the product card. A front panel terminal interface jack labeled CTRL enables you to access the full set of menu-driven diagnostic and configuration controls by a standard terminal interface. Available are loopback and test pattern control, access to performance monitoring, and configuration control. Instructions for using this terminal feature may be found in Chapter 2, Installation and Chapter 3, Operation.

## Equipment List

[Table 1-1](#) lists the UAS 711-D2 part numbers.

**Table 1-1** Equipment List

Description	Part No.
UAS 711-D2	073P215-002
UAS 711-D2 (X.21 Interface)	073M215-012
UAS 711-D2 (530 Interface)	073M215-022
<b>Cables</b>	
Interface cable (HDSL CTRL port to terminal connection) RJ48C plug to 9-pin female	027H250-010
Interface cable, 50-pin Amp connector to six 8-position modular jacks (Each cable can support up to six cards.)	024H608-002
Cable assembly, DB-25M to V.35F	027H572-001
Cable assembly, V.35 straight-through M/F	027H553-xxx
Cable assembly V.35 straight-through M/M	027H570-xxx
Adapter cable 37-pin female to 25-pin male (use with customer provided cable for RS-449 equipment and UAS 711-D2 equipped with EIA-530 Channel Interface Card.)	027H501-001
Cable assembly DB-25M to DB-15F X.21 Adapter	027H436-001
Adapter Cable 37-pin male to 25-pin male (use with customer provided cable for RS449 equipment and UAS 711-D2 equipped with EIA 530 Channel Interface Card.)	023H603-xxx
<b>Enclosure/Shelves</b>	
SpectraComm/UAS Shelf MS-2 Model 2 (-48 Vdc) (Includes two 8-slot, dual RJ45 Zone 1 connector panels)	010M055-001
SpectraComm/UAS Shelf MS-2 Model 1 (100/120 Vac) (Includes two 8-slot, dual RJ45 Zone 1 connector panels)	010M054-001
SpectraComm/UAS Shelf MS-2 Model 3 (220/240 Vac, International) (Includes two 8-slot, dual RJ45 Zone 1 connector panels)	010M056-001
SpectraComm 2000 Shelf	010B226-xxx



# Chapter 2: Installation

---

## Overview

This chapter guides you through the process of installing and using the 711-D2 in your communications network. If this is your first experience using this unit, review *Chapter 1* to ensure that you understand the key features and the process of installing and using the unit in your network.

## Unpacking and Handling

Inspect the unit for damage; if any is observed, notify the shipper immediately. Save the box and packing material; you can use it to reship the unit, if necessary.

## Installation

Place the unit in a ventilated area where the ambient temperature does not exceed 122°F (50°C).

Do not install the unit directly above equipment that generates a large amount of heat (such as power supplies).

### Installation of Shelf

To install the SpectraComm/UAS Shelf, refer to *Installation and Operation SpectraComm/UAS Shelf and Enclosure, GDC 010R302-000*. To install the SpectraComm 2000 Shelf, refer to *Installation and Operation SpectraComm 2000 Shelf, GDC 010R358-000*.

---

**Important** *Install shelves and power supplies as described in the shelf manuals. Failure to do so may result in overheating and subsequent power supply shutdown.*

---

### Setting Hard Options on UAS 711-D2


Setting the hard options on the UAS 711-D2 basecard means adjusting configuration switches and jumpers to match your network operation. [Figure 2-1](#) shows their location and [Table 2-1](#) explains their functions.

---

**Note** *The microprocessor in the UAS 711-D2 reads the switch settings only when you first power up. If you change the settings while the power is on, you must turn the power off and power up again for the new settings to take effect. Soft options that are changed while power is on do not require a power cycle. Soft options are stored in non-volatile memory and do not need to be reset after power interruption.*

---

Make these adjustments only once, when first installing the unit. Do not repeat the procedure unless you change your network or connect a different device to a data channel.



**Figure 2-1** Option Switch and Jumper Locations

**Table 2-1** Option Selection

Switches	Description																					
S34-1 (SOFT)	Off = Soft - Allows 711-D2 configuration control through the terminal or a GDC SNMP managed UAS.																					
	On = Hard - Allows 711-D2 configuration through dip-switch settings.																					
S34-2 (NLP0) S34-3 (NLP1)	Allows a 711-D2 to operate over 1 or 2 HDSL loops: <table><tr><th>NLP0</th><th>NLP1</th><th></th></tr><tr><td>S34-2</td><td>S34-3</td><td></td></tr><tr><td>On</td><td>Off</td><td>HDSL Loops 1 and 2 Enabled</td></tr><tr><td>Off</td><td>On</td><td>HDSL Loop 1 Enabled</td></tr><tr><td>Off</td><td>Off</td><td>HDSL Loops 1 and 2 Enabled</td></tr><tr><td>On</td><td>On</td><td>HDSL Loop 1 and 2 Enabled</td></tr></table>				NLP0	NLP1		S34-2	S34-3		On	Off	HDSL Loops 1 and 2 Enabled	Off	On	HDSL Loop 1 Enabled	Off	Off	HDSL Loops 1 and 2 Enabled	On	On	HDSL Loop 1 and 2 Enabled
NLP0	NLP1																					
S34-2	S34-3																					
On	Off	HDSL Loops 1 and 2 Enabled																				
Off	On	HDSL Loop 1 Enabled																				
Off	Off	HDSL Loops 1 and 2 Enabled																				
On	On	HDSL Loop 1 and 2 Enabled																				
S34-4 (NTU)	Off = NTU - The 711-D2 operates as a network termination unit, located on the user side. On = LTU - The 711-D2 operates as a line termination unit located on the central office side. In this mode the 711-D2 serves as the master unit with respect to timing and supervision of the NTU.																					
S34-5, 6 (Spare)	Future use.																					
S34-7 (CCK0) S34-8 (CCK1)	Selects timing: <table><tr><th>CCK1</th><th>CCK20</th><th></th></tr><tr><td>S34-8</td><td>S34-7</td><td></td></tr><tr><td>Off</td><td>"don't care"</td><td>Looped:</td><td>The DCE transmit clock is locked to the DCE receive clock and is developed from the incoming HDSL timing.</td></tr><tr><td>On</td><td>Off</td><td>Internal:</td><td>The DCE transmit clock is derived from the internal clock oscillator of the 711-D2.</td></tr><tr><td>On</td><td>On</td><td>External:</td><td>The DCE uses an external transmit clock provided by the customer's DTE. When external timing is selected on the LTU 711-D2, the appropriate timing option needs to be set for the DTE. The DTE must provide timing to the Chnl Ext Clk lead.</td></tr></table>				CCK1	CCK20		S34-8	S34-7		Off	"don't care"	Looped:	The DCE transmit clock is locked to the DCE receive clock and is developed from the incoming HDSL timing.	On	Off	Internal:	The DCE transmit clock is derived from the internal clock oscillator of the 711-D2.	On	On	External:	The DCE uses an external transmit clock provided by the customer's DTE. When external timing is selected on the LTU 711-D2, the appropriate timing option needs to be set for the DTE. The DTE must provide timing to the Chnl Ext Clk lead.
CCK1	CCK20																					
S34-8	S34-7																					
Off	"don't care"	Looped:	The DCE transmit clock is locked to the DCE receive clock and is developed from the incoming HDSL timing.																			
On	Off	Internal:	The DCE transmit clock is derived from the internal clock oscillator of the 711-D2.																			
On	On	External:	The DCE uses an external transmit clock provided by the customer's DTE. When external timing is selected on the LTU 711-D2, the appropriate timing option needs to be set for the DTE. The DTE must provide timing to the Chnl Ext Clk lead.																			

**Table 2-1** Option Selection (Cont.)

Switches	Description																		
S35-1 — 4 (Spare)	Future use.																		
S35-5 (V.54)	Off - Unit acknowledges V.54 inband loopback code. On - Unit does not acknowledge V.54 loopback code.																		
S35-6 (RLTM)	On - No RL timeout. Off -10-minute RL timeout.																		
S35-7 (CTS0) S35-8 (CTS1)	<table><tr><td>CTS0</td><td>CTS1</td><td></td></tr><tr><td>S35-7</td><td>S35-8</td><td></td></tr><tr><td>Off</td><td>On</td><td>CTS on if HDSL is operating normally</td></tr><tr><td>On</td><td>Off</td><td>CTS tracks RTS</td></tr><tr><td>Off</td><td>Off</td><td>CTS on if HDSL is operating normally</td></tr><tr><td>On</td><td>On</td><td>CTS on if HDSL is operating normally</td></tr></table>	CTS0	CTS1		S35-7	S35-8		Off	On	CTS on if HDSL is operating normally	On	Off	CTS tracks RTS	Off	Off	CTS on if HDSL is operating normally	On	On	CTS on if HDSL is operating normally
CTS0	CTS1																		
S35-7	S35-8																		
Off	On	CTS on if HDSL is operating normally																	
On	Off	CTS tracks RTS																	
Off	Off	CTS on if HDSL is operating normally																	
On	On	CTS on if HDSL is operating normally																	
S36-1 — S36-6 (CKS, 1— 6)	See continuation of <a href="#">Table 2-1</a> on next page.																		
S36-7, 8 (Spare)	Future use.																		
Jumpers	Description																		
X2, X3	Must be installed.																		
X5	Must be installed.																		
X6	Must be installed in the 2-3 position for the 073P--- (V.35 I/F). For the 073M----012 (X.21 I/F) and 073M----022 (530 I/F) units, X6 must be installed in the 1-2 position.																		



**Table 2-1** Option Selection (Cont.)

<b>Data Rate (X64 kbps)</b>	<b>S36-6</b>	<b>S36-5</b>	<b>S36-4</b>	<b>S36-3</b>	<b>S36-2</b>	<b>S36-1</b>
24	Off	Off	Off	Off	Off	Off
24	Off	On	On	On	On	On
24	On	Off	Off	Off	Off	Off
24	On	Off	Off	Off	Off	On
24	On	Off	Off	Off	On	Off
24	On	Off	Off	Off	On	On
24	On	Off	Off	On	Off	Off
24	On	Off	Off	On	Off	On
24	On	Off	Off	On	On	Off
24	On	Off	Off	On	On	On
23	On	Off	On	Off	Off	Off
22	On	Off	On	Off	Off	On
21	On	Off	On	Off	On	Off
20	On	Off	On	Off	On	On
19	On	Off	On	On	Off	Off
18	On	Off	On	On	Off	On
17	On	Off	On	On	On	Off
16	On	Off	On	On	On	On
15	On	On	Off	Off	Off	Off
14	On	On	Off	Off	Off	On
13	On	On	Off	Off	On	Off
12	On	On	Off	Off	On	On
11	On	On	Off	On	Off	Off
10	On	On	Off	On	Off	On
9	On	On	Off	On	On	Off
8	On	On	Off	On	On	On
7	On	On	On	Off	Off	Off
6	On	On	On	Off	Off	On
5	On	On	On	Off	On	Off
4	On	On	On	Off	On	On
3	On	On	On	On	Off	Off
2	On	On	On	On	Off	On
1	On	On	On	On	On	Off
0	On	On	On	On	On	On

## EIA-530 or X.21 Interface Card

The optional EIA-530 or X.21 Interface Card provides these interfaces for the DTE. They are available factory installed, or as a field upgrade kit. They plug into the base card illustrated in [Figure 2-1](#). (You can also remove the card (s), place jumpers on XA1J2 and XA1J3, and move jumper X6 to make the base card interface active.) When you install the optional X.21 Interface Card in the active position, DTE control of Remote Terminal Test and Local Loopback is not supported. *Appendix C* describes the signals exchanged through the business equipment interface. Optional transmit signal timing, X.21 Interface Card jumper position BT, (Byte Timing) is not supported.

## Installing the UAS 711-D2

Install the UAS 711-D2 card in the shelf following the directions below:

1. Insert the card into its slot with the GDC logo on top (or to the right if the SpectraComm 2000 Shelf is used), then slide it in until it makes contact with the rear panel connectors.
2. Pull down the insertion/extraction tab on the front panel and firmly push the card in until it seats in the rear connectors.

To remove a card, pull down the insertion/extraction tab to unseat the card, then use tab to remove card.

## Electrical Lines

The following paragraphs describe the power and communication line connections to the 711-D2.

### Power Line


The 711-D2 gets its power directly from the shelves.

## Communications Line


See [Figure 2-2](#) for cabling the SpectraComm/UAS Shelf or the SpectraComm 2000 Shelf.

### SpectraComm/UAS Shelf

8-slot Zone 1 connector panel - two RJ48C/X 8-position module jacks per slot. The lower jack is for the HDSL network. *Appendix B* describes the pin-outs for this interface.



### SpectraComm 2000 Shelf



NOTE: Cables are customer provided.  
Drawings are shown to clarify cable use.

**Figure 2-2**

Rear Panel Shelf - Cabling

## Preoperational Configuration Setup

### Hard

Configure the 711-D2 as follows:

1. On the basecard, verify that jumpers X2, X3, and X5 are installed.
2. Check that X6 is installed in the proper position, based on [Table 2-1](#).
3. Check that the card is configured as an LTU or NTU based upon [Table 2-1](#).
4. Set the remaining switches and jumpers according to [Table 2-1](#) and [Figure 2-1](#). If S34-1 is placed in the **SOFT** configuration position, all other switch settings are ignored, and the unit must be configured via the optional terminal screen. *Refer to Preoperational Configuration Setup Soft.*
5. Connect the DTE interface and HDSL loops to the network connectors on the rear panel of the shelf.
6. Insert the card (NTU or LTU) into a previously powered-up shelf. The card automatically performs internal self-tests.
7. Follow *Step 4* under *Preoperational Configuration Setup Soft*.

### Soft

1. Follow Steps 1 through 6 above.
2. Connect a terminal to the CTRL connector on the front panel.
3. To view the test results on the terminal, go to the View H/S Config Screen on the terminal. Refer to *Chapter 3, Soft Configuration and Control* for details in configuring the unit using the supervisory terminal.
4. After performing the self-tests, the HDSL loops (LTU and NTU) initiate start-up, and the HDSL green LEDs should blink. The start-up should last less than 3 minutes. When complete, the HDSL NORM LEDs should be on and the HDSL ES LEDs should be off. If not, the start-up failed. The two cards automatically initiate a new start-up procedure. During this time, the ALM LED blinks until all HDSL status indicators clear.
5. Data transfer should occur, DTE indicators RD and SD should be on. The NORM LED should be on, and the ES LED should be off. If not, refer to the troubleshooting procedure in *Chapter 4*.

# Chapter 3: Operation

---

## Overview

This chapter describes the operation of the UAS 711-D2. It is managed through the front panel supervisory port (CTRL), hard options and the shelf resident SpectraComm Manager (SCM) card with associated SNMP manager.

## Front Panel

[Figure 3-1](#) illustrates the UAS 711-D2 front panel and explains the function of each LED indicator and the CTRL port. Check the operation of the unit by monitoring the front panel indicators and using the test procedures provided in *Chapter 4*. Unit configurations for typical applications are in *Chapter 5*. Once the options are set and the communication line properly connected, the units need no additional operator commands. The units are transparent to your network and communicate automatically with each other and with your connected network devices.

---

**Note** *You will see that all front panel LEDs are ON for approximately 2 seconds after you have applied power to the card or after the card has undergone a reset.*

---




Figure 3-1 Front Panel

## Soft Configuration and Control

You can use an optional terminal (a standard ASCII terminal equipped with an EIA/TIA-232-E communication interface) connected to the CTRL jack on the front panel for configuration and control of the UAS 711-D2.


### Terminal Requirements

Any standard ASCII terminal (VT100 or ANSI terminal or personal computer emulating an ASCII terminal) equipped with an EIA/TIA-232-E communication interface may be used to control the UAS 711-D2 operation. The following screens were derived by plugging the COMM port of a PC (using Microsoft Windows™ terminal emulator program) into the UAS 711-D2 front panel CTRL jack. Set the terminal communications parameters as follows:

- Data Rate = 9600 bps, Character Format = 1 start bit, 8 data bits, no parity, 1 stop bit, handshake = none.
- The software necessary to run the UAS 711-D2 supervision program is contained in the UAS 711-D2.

## Startup Procedure

A management session automatically starts as soon as the terminal cable is connected to the CTRL port of an operating UAS 711-D2. To end an ongoing management session, disconnect the terminal from the UAS 711-D2. Upon power-up, the UAS 711-D2 sends the opening screen, showed in [Figure 3-2](#), followed by the main menu.



**Figure 3-2** Opening Screen

## Screen Organization

The screen includes the areas described in [Table 3-1](#).

**Table 3-1** Terminal Screen Organization

Field	Description
Header	Located at the top of the screen, the header displays GDC name and equipment model, followed by the current operating mode (LTU or NTU), and the date and time sent by the UAS 711-D2.
Status Line	Located below the header, the status line includes two main fields, which display the status of the various UAS 711-D2 alarms and status signals. Active alarm and status indicators are displayed in reverse video.
DCE Field	Includes the following indications: TM, DCD, DTR, RTS, DSR
Loop 1, 2 Alarms Field	Loop alarms field is divided into several sub fields, one for each loop and includes the following indications: LOS - Loss of input signal on the corresponding loop. UAS - Unavailable seconds threshold for the corresponding loop is being exceeded. LOSW - Loss of synchronization word on the corresponding loop. MAJ - Selected major alarm bit error rate threshold has been exceeded. Used to estimate the BER of an individual 784 kbps HDSL loop. MIN - Selected minor alarm bit error rate threshold has been exceeded. Used to estimate the BER of an individual 784 kbps HDSL loop.
Work Area	Displays the menu and dialog boxes.
Active Keys Area	The active keys are constantly updated to show the keys and key combinations you can use on the current screen.

## Operating Procedures

The following procedures apply to all the operations that you perform on the optional terminal.

### Menu Selection

You can select a menu item in two ways:

1. Move the selected block to the desired item by means of the keyboard arrows, then press the Enter key.
2. Type the number appearing to the side of the menu item.

Either action opens the sub menu or dialog box used to perform the selected operation.

### Field Navigation

To move forward among the fields of a dialog box, press the Down arrow key (↓). To move backward, press the Up arrow (↑) key.

### Field Editing

You can modify the values displayed in the screen fields as follows:

1. Bring the cursor to the desired field; press Enter to display an option menu with the available values.
2. Highlight the desired value; press Enter to select the new value and close the option menu.



## Restoring Default Values

When the UAS 711-D2 stores default values for parameters displayed in a dialog box, you can replace the current values with the default values by pressing **Ctrl-D** (**Ctrl-D** means hold down the **Ctrl** (control) key and press **D**).

## Saving Values

To save new parameter values entered in dialog boxes, press **Ctrl-W**. These parameters are stored in non-volatile memory for use upon the next unit power-up in **SOFT Config mode** (S34-1 switch is set to **SOFT**).

## Quitting Without Saving


To quit without saving the new parameter values entered in a dialog box, press **Esc**. You can also press **Esc** as necessary to close any open submenus and to return to the main menu.

## Refresh

You may refresh the screen at any time by typing **Ctrl-R**.

## Main Menu

The Main Menu is displayed in [Figure 3-3](#). The menu includes three options, described in the following paragraphs.



**Figure 3-3** Main Menu

## Diagnostics

Use this option to display diagnostic information and to activate or control diagnostic functions, as follows:

- Display of performance statistics collected on each of the HDSL loops.
- Display HDSL loop status information, technical data on loop performance, HDSL loop noise margins, etc.
- Cancel the start-up process.

## Configuration

Use this option to configure the data interface and HDSL loop parameters, as follows:

- Modify the HDSL loop operating mode (NTU or LTU), number of loops enabled, and major and minor alarm thresholds.
- Display and modify the interface configuration, TX Clock mode, CTS mode, V.54 options, Remote Loopback time-out options, and Data Rate.
- Display system hardware and software data and UAS 711-D2 self-test results.

## Maintenance


Use this option to perform maintenance activities, as follows:

- Enable both local and remote system loopbacks.
- Test system performance using the internal UAS 711-D2 BER tester (meter).
- Set the real-time clock.
- Reset the statistics counters.
- Manually initiate the start-up process.
- Reset the UAS 711-D2. (Simulate a power-up.)

These screens are described in *Chapter 4* under Maintenance Menu.

## Diagnostic Menu

Use the diagnostic menu to display diagnostic information, and to activate diagnostic functions. See [Figure 3-4](#). To open Diagnostics, select Item 1 on the Main Menu.




**Figure 3-4** Diagnostic Menu

The functions available from the diagnostic menu are:

- HD SL Monitoring
- HD SL Status
- Cancel Startup

## HD SL Monitoring

The HD SL Monitoring screen, [Figure 3-5](#), displays 24-hour performance statistics on the HD SL loops. To display HD SL Monitoring, select Item 1 on the Diagnostic menu.



**Figure 3-5** HDSL Monitoring Screen

The screen includes the fields described in [Table 3-2](#).

**Table 3-2** HDSL Monitoring Screen

Field	Description
Cyclic Pointer	Displays the number sequence of the current 15-minute interval within the current 24-hour interval. The range is 0 to 95. HDSL error statistics ES, UAS, and SES are reported consistent with ITU G.821.
Interval Time	Displays the elapsed time in seconds from the beginning of the current 15-minute interval. The range is 0 to 900.
ES	Displays the number of errored seconds in the current 15-minute interval.
Last 24 Hr ES	Displays the number of errored seconds in the last 24-hour interval.
UAS	Displays the number of unavailable seconds in the current 15-minute interval.
Last 24 Hr UAS	Displays the number of unavailable seconds in the last 24-hour interval.
SES	Displays the number of severely errored seconds in the current 15-minute interval.
Last 24 Hr SES	Displays the number of severely errored seconds in the last 24-hour interval.
FEBE	Displays the number of Far-End-Block-Errors reported by the remote equipment in the current 15-minute interval.
Last 24 Hr FEBE	Displays the number of Far-End-Block-Errors reported in the last 24-hour interval.

To select another loop, type its number: 1 or 2.

**Note**

*Powering up the UAS 711-D2 resets the 24 hour performance statistics on the HDSL loops.*

After viewing the data collected for the selected loop in the current 15-minute interval, you can display the other 95 intervals within the current 24-hour interval by pressing any key, except 1, 2, 3, R, and Esc keys. The display is cyclic, that is, the current interval is displayed again after the 95th interval.

To reset the HDSL statistics counters, type `R`. All the displayed values are reset to 0.

To exit and return to the `Diagnostics` menu, press `Esc`.

HDSL Status

The option displays the HDSL Status screen, which shows you diagnostic information and technical data on HDSL loop performance. A typical screen is shown in [Figure 3-6](#).




Figure 3-6 HDSL View Screen

[Table 3-3](#) describes the fields on the HDSL Status screen.

**Table 3-3** HDSL Status Screen Fields

Field	Description
Loops Exchange	Indicates whether the HDSL loops carrying the data traffic are correctly connected or have been interchanged by error. This information is available only when the unit connected in a link can exchange information with the remote unit. Not applicable if unit is configured as an LTU.
Loop 1 TIP/RING Reversal	Indicates whether the two conductors of HDSL Loop 1 are correctly connected or have been interchanged by error. This information is available only when the unit connected in a link can exchange information with the remote unit. Not applicable if unit is configured as an LTU.
Loop 2 TIP/RING Reversal	Indicates whether the two conductors of HDSL Loop 2 are correctly connected or have been interchanged by error. This information is available only when the unit connected in a link can exchange information with the remote unit. Not applicable if unit is configured as an LTU.
Noise Margin	Displays amount of additional noise in dB which can be tolerated before exceeding $5 \times 10^{-8}$ bit error ratio. Separate values are provided for each HDSL loop.
Pulse Attenuation	Displays the pulse attenuation, in dB, measured by the signal processing circuits of the UAS 711-D2. Separate values are provided for each HDSL loop for the local unit.

### Operation

To display HDSL Status, select Item 2 on the Diagnostics menu. After viewing the data, press `Esc` to exit and return to the Diagnostics menu.

### Cancel Startup


Cancel Startup is used to cancel the start-up process performed by the UAS 711-D2 upon link initialization and whenever the synchronization between two GDC HDSL units connected in a link is lost. This function enables partial operation under fault conditions.

### Operation

To select Cancel Startup, select Item 3 from the Diagnostics menu.

## Configuration Menu

Use the Configuration menu to configure the data interface and the HDSL loop parameters. To open the Configuration menu, select Item 2 on the Main Menu. [Figure 3-7](#) depicts the Configuration menu.




**Figure 3-7** Configuration Menu

The functions available from the Configuration menu are as follows:

- Unit Config.
- Interface Config.
- View H/S Config.

## Unit Configuration Screen

Select 1. Unit Config. To display the Unit Configuration screen and show the HDSL configuration parameters of the UAS 711-D2. A typical screen is shown in [Figure 3-8](#).



**Figure 3-8** Unit Configuration Screen

The screen includes four fields, which are used to select the operating mode of the UAS 711-D2 on the HDSL loops side, and the network application:

- Unit Type
- Enabled Loops
- Maj Alm Thres (Major Alarm Threshold)
- Min Alm Thres (Minor Alarm Threshold)

### Operation


1. To display the Unit Configuration screen, select Item 1 on the Configuration menu.
2. To change the current selection for Unit Type, press Enter. This displays an option menu with the available options:
3. LTU
4. NTU
5. Highlight the desired option and press Enter. The option menu closes and the new selection appears in the screen.
6. To change the current value of the Enabled Loops field, select Item 2 on the unit configuration menu. A menu displays the number of loops with options of 1 and 2.
7. Highlight the desired number and press Enter to select it.



8. To change the current major alarm, bit-error rate threshold, select Item 3 on the Unit Configuration menu. This value is changed in the same way as other unit configuration items. Available selections are  $10^{-4}$ ,  $10^{-5}$ ,  $10^{-6}$ ,  $10^{-7}$ , and  $10^{-8}$ .
9. To change the current minor alarm, bit-error rate threshold, select Item 4 on the Unit Configuration menu. This value is changed the same way as other unit configuration items. Available selections are  $10^{-4}$ ,  $10^{-5}$ ,  $10^{-6}$ ,  $10^{-7}$ , and  $10^{-8}$ .
10. After making the desired changes, press **Ctrl-W** to save the changes in the UAS 711-D2. To quit and cancel changes made in this screen, press the **Esc** key without pressing **Ctrl-W**.
11. To exit and return to the configuration menu, press **Esc**.

## Interface Configuration Screen

Selecting Interface Config. displays DCE Interface Configuration parameters of the UAS 711-D2. A typical screen is shown in [Figure 3-9](#).



**Figure 3-9** The screen includes the fields described in [Table 3-4](#). Interface Configuration Screen

**Table 3-4** Interface Configuration Screen

Field	Description
TX Clock Mode	Displays the DCE interface transmit timing selection: Looped - The DCE transmit clock is locked to the DCE receive clock and is developed from the incoming HDSL timing. External - The DCE interface uses an external clock provided by your DTE. When external timing is selected on the LTU UAS 711-D2, the appropriate timing option needs to be set for the DTE. The DTE must loop timing from the Chnl Rcv Clk lead to the Chnl Ext Clk lead. Internal - The DCE transmit clock is derived from the internal clock oscillator of the UAS 711-D2.
CTS Mode	On: CTS is on as long as the HDSL module is powered and operating normally. On with RTS: The CTS line tracks the state of the RTS line.
V54 Rx Mode	Enabled: The UAS 711-D2 detects and responds to inband V.54 protocol. Disabled: The UAS 711-D2 does not respond to inband V.54 protocol.
RL Timeout	None: Remote loopback remains on indefinitely. 10 Min: Remote loopback is disabled after 10 minutes.
Data Rate	Press the <code>space bar</code> to increment the data rate, press the <code>minus</code> key to decrement the data rate. Select from N=1 to N=12 when one loop is enabled or N=1 to N=24 when both loops are enabled.

## Operation

To select Interface Config., select Item 2 on the Configuration menu.

To change the current value of a parameter, use the following procedure:

1. Move the selection block to the desired line and press `Enter`.

An option menu appears with the available options.

2. Highlight the desired option, and press `Enter`. The option menu closes, and the new selection appears in the corresponding line.
3. To reset the selected parameters to the default values, press `Ctrl D`.
4. To save changes, press `Ctrl W`.
5. To quit and cancel the changes made in this screen, press `Esc`.
6. To exit and return to the Configuration menu, press `Esc`.

## T1 Service Provisioning Options

The UAS 711-D2 provisions the payload across the HDSLK loops as shown below

Routed T1 timeslots over HDSL loops.

```


Loop 1  1   2   3   4   5   6   7   8   9  10  11  12
Loop 2 13  14  15  16  17  18  19  20  21  22  23  24

```

When optioning the 711-D2 for one loop, the start DS0 and consecutive DS0's can be allocated through the network configuration screen with a maximum of twelve DS0's per loop.

## View H/S Configuration

The View H/S Configuration option displays the Configuration and Selftest Results screen, showing hardware and software configuration data and the results of the last power-up self-test. The information displayed on this screen is intended for maintenance and technical support groups. A typical screen is shown in [Figure 3-10](#).



**Figure 3-10** View H/S Configuration Screen

The upper area of the screen presents configuration data. The lower area presents the results of the last power-on self-test. [Table 3-5](#) describes the fields in the screen.

**Table 3-5** Configuration and Selftest Results Screen Fields

Software Version	Displays the software version of the UAS 711-D2.
Number of Loops	Displays the number of HDSL loops of the UAS 711-D2.
Serial Number	Displays serial number of unit.
Checksum	Firmware checksum.
Config Mode	Displays the current configuration mode of the UAS 711-D2: Soft - The UAS 711-D2 is configured under software control. Hard - The UAS 711-D2 is configured by means of the internal dip switches and jumpers.

The last power-on self-test results area lists each UAS 711-D2 subsystem tested during the self-test, and the self-test result: Pass or Fail.

## Maintenance Menu

Refer to *Chapter 4* to perform maintenance and troubleshooting.

## Network Management

The UAS 711-D2 can be used as a Network Managed element when used within a GDC Network Management System. The UAS 711-D2 management software conforms to the MIB (Management Information Base) II standards set out for SNMP Version 1.0. Refer to the related SCM Manager Card publication listed in the Preface.

### MIB Tables

[Table 3-6](#) through [Table 3-15](#) list and describe the MIB objects by which an SNMP network manager can configure, control, and monitor the UAS 711-D2. Each table is arranged in five columns:

- MIB Object: name
- Syntax: MIB variable type
- Access: read-write, read-only, or write-only
- Enumeration: interpretation of specific possible values, or range of possible values
- Description: function of the MIB object

The way MIB objects appear on the screen and how they are manipulated varies depending on the network manager or MIB browser being used. The information in these tables is therefore intended for use in conjunction with the operating instructions for the manager or browser.

---

**Note** *Many SNMP network managers and MIB browsers automatically perform a Get operation immediately following a Set to an object that permits read-write access. In that way you confirm the success of the write operation. If your manager or browser does not perform this function automatically, we advise that you command a Get for each object you Set*

---

[Table 3-16](#) is a list of HDSL alarms.

**Table 3-6** Version Group

MIB Object	Syntax	Access	Enumeration	Description
System MIB Version	Display String	Read-only		Identifies the version of the MIB. The format of the version is x = yzT, where x identifies the major revision number, y identifies the typographical revision, and T identifies the test revision. (not on formal release) Acceptable values for the individual revision components are: x: 1 - 9 y: 0 - 9 z: 0 - 9 T: A - Z
Version Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and sub-identifier. The table describes the maintenance objects for the unit and references the unit interface.
Firmware Level	Display String	Read-only		The version number of the firmware. This allows the products to know which revision is installed. The released version number is sequenced from, A,...AA,...ZZ. Test versions are numerical from 01 to 99.
Model Number	Display String	Read-only		This variable is used to determine the type of card family installed.

**Table 3-7** Maintenance

MIB Object	Syntax	Access	Enumeration	Description
Maintenance Line Index	SC instance	Read-only		Index value uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and sub-identifier. The table describes the maintenance objects for the unit and references the unit interface.
Soft Reset	SC instance	Read-write	Reset (1) Norm (2)	Supports the action of soft resetting the unit. When this object is set to reset, the unit performs a soft reset to the managed unit. Norm cannot be set by management.

**Table 3-7** Maintenance (Continued)

MIB Object	Syntax	Access	Enumeration	Description
Config Mode	Integer	Read-only	Software (1) Hardware (2)	Hardware configuration mode of the unit. A unit may be hardware or software configured.
System Up Time	Time Ticks	Read-only		This variable is used to report the elapsed system tick time.
Unit Type	Integer	Read-write	LTU (1) NTU (2)	Used to define HDSL type. LTU selects line terminating unit, NTU selects network terminating unit. For 700-G2/G3, this variable can only be a LTU.
Default Initiate	Integer	Read-write	Default (1) Normal(2)	Used to allow the non volatile configuration to be set to a factory default reset. Normal cannot be set by management.
Data Type	Integer	Read-write	Data (2) Voice (1)	Defines the HDSL data type as Data for the UAS 711-D2.
Number of Loops Enabled	Integer	Read-write	One Loop (1) Two Loops (2)	Used to define the HDSL loop configuration. It can be set for one to two loops.
Private Storage 1	Display String	Read-write	(Size (16))	This variable is used for general purpose storage.
Private Storage 2	Display String	Read-write	(Size (16))	This variable is used for general purpose storage.
Private Storage 3	Display String	Read-write	(Size (16))	This variable is used for general purpose storage.
LED Status	Octet String	Read-only	Octet 1 Bit 7 - not used Bit 6 - EIA RD Bit 5 - EIA CO Bit 4 - EIA RS Bit 3 - NORM E1 Bit 2 - ES E1 Bit 1 - AL Bit 0 - TM Octet 2 Bit 7 - not used Bit 6 - EIA SD Bit 5 - not used Bit 4 - not used Bit 3 - NORM L2 Bit 2 - ES L2 Bit 1 - NORM L1 Bit 0 - ES L1	Returns a bit-wise snapshot of the front panel LED status.

**Table 3-8** TDTE Configuration

MIB Object	Syntax	Access	Enumeration	Description
DTE Config Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop.
DTE CTS Mode	Integer	Read-write	Forced On (1) On With RTS (2)	Controls the function of CTS.
DTE Data Rate	Integer	Read-write	(1.32)	This variable represents the DTE data rate in 64 k increments.
DTE TX Clock Source	Integer	Read-write	External Timing (1) Internal Timing (2) Loop Timing (3)	External timing indicates that recovered receive clock from another interface is used as the transmit clock. Internal indicates that a local clock source is used. Loop Timing indicates that the recovered receive clock is used as the transmit clock.

**Table 3-9** HDSL Diagnostics

MIB Object	Syntax	Access	Enumeration	Description
Diagnostic Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and sub-identifier, which is in this case, a network interface.
Loopback	Integer	Read-write	No Loopback (1) Line Loop (2) Local Loop (3) Line and Local Loop (4)	Supports the action of a diagnostic loop at the point indicated.
BER Test	Integer	Read-write	Inhibit (1) Enable (2) Reset (3)	Supports the action of bit error rate test. When set to inhibit, no BERT test is in progress. When set to enable, BERT is in progress. When set to Reset, the BERT result is reset.

**Table 3-10** Alarm Threshold Configuration

MIB Object	Syntax	Access	Enumeration	Description
Alarm Configuration Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and sub-identifier, which is in this case, a network interface, including loop 1 and loop 2.
Alarm Configuration Identifier	Object Identifier	Read-only		The unique alarm identifier assigned to this alarm type. The format of this identifier is an Object Identifier that has the following format: {iso (1) org (3) dod (6) internet (1) private (4) enterprises (1) gdc (498) xxx (x) alarm (z) yyy (y) where xxx (x) is the administratively assigned family object identifier, (z) is the object identifier for alarms in the family defined MIB, and yyy (y) is the administratively assigned alarm type identifier for this alarm. See example below.
<div style="text-align: center;">           1    3    6    1    4    498    5    2    10            └──────────────────┘ └──┘ └──┘            Administration Family ID ←            Object ID for Alarm Family ←            Administration Assigned Alarm ←         </div>				
Alarm Threshold	Integer	Read-write	thres1E04 (1) thres1E05 (2) thres1E06 (3) thres1E07 (4) thres1E08 (5) thres1E09 (6)	Sets the Major or Minor alarm threshold criteria.



**Table 3-11** HDSL Diagnostic Results

MIB Object	Syntax	Access	Enumeration	Description
Diagnostic Results Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and sub-identifier, which is in this case, a network interface.
Test Execution Status	Integer	Read-only	In Sync (1) Not In Sync (2)	The current execution status of the diagnostic test. When set to In Sync, BERT test is in sync and BER rate is valid. When set to Not In Sync, BERT test is not in sync, and BER rate is not valid.
	Integer	Read-only	(0..65535)	The results of the last diagnostic test. This can be the current test running or the last completed test. Note that the interpretation of these test results may be affected by the value of the Test Execution Status object.
Diagnostic Result Interval	Integer	Read-only	(0..65535)	This variable represents the BER test intervals. A time interval is defined as the time required for transmission of a block of bits.

Table 3-12 HDSL Performance

Current Performance Table				
MIB Object	Syntax	Access	Enumeration	Description
HDSL Current Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and interface, which in this case, can be an E1 or loop interface.
HDSL Current ESs	Gauge	Read-only		The number of errored seconds encountered by an E1 or loop interface in the current 15 minute interval.
HDSL Current SESSs	Gauge	Read-only		The number of severely errored seconds encountered by a loop or E1 interface in the current 15 minute interval.
HDSL Current UASs	Gauge	Read-only		The number of degraded seconds encountered by a loop or E1 interface in the current 15 minute interval.
HDSL Current DMs	Gauge	Read-only		The number of degraded minutes encountered by a E1 interface in the current 15 minute interval.
HDSL Current FEBEs	Gauge	Read-only		The number of Far End Block Errors encountered by a loop interface in the current 15 minute interval.
Internal Performance Table				
HDSL Interval Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and interface, which in this case, can be an E1 or loop interface.
HDSL Interval Number	Integer	Read-only	(1..96)	A number between 1 and 96, where 1 is the most recently completed 15 minute interval and 96 is the least recently completed 15 minute interval (assuming that all 96 intervals are valid).
HDSL Interval LESSs	Gauge	Read-only		The number of errored seconds encountered by a loop or E1 interface in one of the previous 97 individual 15 minute intervals.
HDSL Interval SESSs	Gauge	Read-only		The number of severely errored seconds encountered by a loop or E1 interface in one of the previous 96 individual 15 minute intervals.
HDSL Interval UASs	Gauge	Read-only		The number of unavailable seconds encountered by a E1 interface in one of the previous 96 individual 15 minute intervals.
HDSL Interval DMs	Gauge	Read-only		The number of degraded minutes encountered by a loop or E1 interface in one of the previous 96 individual 15 minute intervals.

**Table 3-12** HDSL Performance (Continued)

Total Performance Table				
MIB Object	Syntax	Access	Enumeration	Description
HDSL Interval FEBEs	Gauge	Read-only		This variable represents the HDSL loops Far End Block Errors.
HDSL Total Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and interface, which is in this case, can be an E1 or loop interface.
HDSL Total ESs	Gauge	Read-only		The number of errored seconds encountered by an E1 or loop interface in the previous 24 hour interval.
HDSL Total SESs	Gauge	Read-only		The number of severely errored seconds encountered by a loop or E1 interface in the previous 24 hour interval.
HDSL Total UASs	Gauge	Read-only		The number of unavailable seconds encountered by a loop or E1 interface in the previous 24 hour interval.
HDSL Total DMs	Gauge	Read-only		The number of degraded minutes encountered by a E1 interface in the previous 24 hour interval.
HDSL Total FEBEs	Gauge	Read-only		The number of Far End Block Errors encountered by a loop interface in the previous 24 hour interval.

**Table 3-13** Loop/E1 Performance Interval Maintenance

MIB Object	Syntax	Access	Enumeration	Description
HDSL Interval Maintenance Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop, and interface, which in this case, can be an E1 or loop interface.
HDSL Reset Intervals	Integer	Read-write	Normal (1) Reset (2)	This variable is used to reset loop/E1 performance intervals. When it is set to reset, the loop/E1 performance tables are set to zero.
HDSL Number of Valid Intervals	Integer	Read-only	(1..96)	This variable is used to read the number of intervals collected. Each interval is an increment of 15 minutes.

**Table 3-14** HDSL Status

MIB Object	Syntax	Access	Enumeration	Description
HDSL Loop Status Line Index	SC instance	Read-only		This object identifies status parameters associated with the managed object.
HDSL Loop Startup	Integer	Read-write	Normal (1) Start (2) Cancel (3)	Supports the action of initializing HDSL loop startup sequence. When set to start, HDSL unit reinitializes the startup sequence. Set to cancel, the unit aborts the startup sequence. Normal, the unit operates normally.
HDSL Loop Tip and Ring Reversal Mode	Integer	Read-only	Normal (1) Reversed (2)	Signals the loop Tip and Ring status. When normal, the loop operates normally. When reversed, loop Tip and Ring have been reversed.
HDSL Loop Signal to Noise Margin	Integer	Read-only	(0..127)	Represents the loop signal to noise margin in dB units.
HDSL Loop SN Frac	Integer	Read-only	(0..5)	Used with the HDSL loops signal to noise margin variable in the following manner: 1. Only the values 0 and 5 are allowed. 2. The value of zero means HDSL loops signal to noise margin is a whole number. 3. The value of five means HDSL loop signal to noise margin is a real number and that 0.5 must be added to it.
HDSL Loop SN Atten Sense	Integer	Read-only	Positive (1) Negative (2)	Identifies the sense of the HDSL loop signal to noise margin variable.
HDSL Loop Pulse Atten	Integer	Read-only	(0..100)	Represents twice the HDSL loop pulse attenuation level in dB units.
HDSL Loop Pulse Atten Frac	Integer	Read-only	(0..5)	This variable is used with the HDSL loop pulse attenuation variable under the following conditions: 1. Only the values 0 and 5 are allowed. 2. The value of zero means HDSL Loop Pulse Atten is a whole number. 3. The value of five means HDSL Loop Pulse Atten is a real number and that 0.5 must be added to it.
HDSL Loop Gain	Integer	Read-only	Low (1) High (2) OK (3)	Represents the HDSL loop gain setting.
HDSL Loop Exchange	Integer	Read-only	Normal (1) Exchange (2)	This variable is used to represent the HDSL loop status. When set to normal, HDSL loops are correctly connected. Set to exchange, the HDSL loop has been interchanged.

**Table 3-15** DTE Status (DTE Interface Only)

MIB Object	Syntax	Access	Enumeration	Description
DTE Status Index	SC instance	Read-only		The index value that uniquely identifies the interface to which this entry is applicable. SC instance defines the slot, line, drop.
DTE DTR Status	Integer	Read-only	Off (1) On (2)	DTR EIA status indicator.
DTE DCD Status	Integer	Read-only	Off (1) On (2)	DCD EIA status indicator.
DTE RTS Status	Integer	Read-only	Off (1) On (2)	RTS EIA indicator.

**Table 3-16** HDLS Alarm Object Identifier Definitions

Alarm Name	Maskable?	Applies To
HDLS No Response Alarm	No	Unit
HDLS Diagnostic Rx Error Alarm	No	Unit
HDLS Power Up Alarm	No	Unit
HDLS Unit Failure	No	Unit
HDLS Check Sum Corrupt	No	Unit
HDLS Loss of Signal	Yes	L1, L2
HDLS Unavailable Second	Yes	L1, L2
HDLS Errored Second	Yes	L1, L2
HDLS Loss of Sync Word	Yes	L1, L2
HDLS Major Alarm	Yes	L1, L2
HDLS Minor Alarm	Yes	L1,L2



# Chapter 4: Tests

---

## Overview

This chapter describes troubleshooting procedures, loopback testing, and the Maintenance Menu screens and descriptions.

---

**Important** *The activation of any loopback disrupts the flow of user traffic.*

---

The UAS 711-D2 displays the status of these tests through the LED indicators on the front panel. You may also use the optional terminal connected to the front panel control (CTRL) port which provides a comprehensive set of features for testing operation and identifying trouble areas. This chapter provides instructions for managing the UAS 711-D2 system with this terminal and tells you how to enable and disable various loopbacks.


If you cannot resolve problems with the UAS 711-D2 using the following procedures, please contact VITAL Network Services listed in the preface of this manual.

## Troubleshooting

- LEDs are OFF:  
If the terminal is working, check the status of voltage 1 and voltage 2 on the terminals View H/S Config screen.
- Start Up Continuously Fails:
  1. If an HDSL red ES LED is continuously on during start-up, the card is not receiving a signal from the far end of its channel. Check the loop connections between the two cards (LTU and NTU).
  2. Verify that one card is configured as LTU and the other as NTU.
  3. Check the status of the card in the View H/S Config screen.

## Maintenance Menu

The Maintenance menu is used to perform maintenance and troubleshooting activities. To open the Maintenance menu, select Item 3 on the Main Menu. [Figure 4-1](#) illustrates the Maintenance menu.



**Figure 4-1** Maintenance Menu

The functions available from the Maintenance menu are as follows:

- Loopbacks
- BER Test
- Set RTC
- Reset Statistics
- HDLSL Startup
- Board Reset



## Loopback Testing


You may initiate all loopback testing via the shelves backplane management bus, supervisory port or DTE control leads. The UAS 711-D2 provides four types of test loopbacks:

1. Line Loopback (LL)
2. Local HDSL Loopback
3. Remote Digital Loopback
4. V.54 Remote Digital Loopback

In addition, the following Self-Tests may be performed:

1. PRBS Generator and BER Meter - The UAS 711-D2 has the ability to replace data in incoming DTE data with a PRBS (Pseudo Random Bit Sequence  $2^{15}-1$ ) and to examine incoming HDSL timeslots for the PRBS with a BER Meter. This self-test generator/checker is available on a per loop or total payload basis. You may use the PRBS generator and BER meter in conjunction with Remote Loopback to test the integrity of the HDSL line.
2. Unit Self Test - The UAS 711-D2 performs a card test at power-up. This test checks memory and as much of the data path as possible.

[Figure 4-2](#) shows the simplified signal paths when the loopbacks are connected.



**Important** The activation of any loopback disrupts the flow of traffic.

### Line Loopback [1]

Data received from the local user DTE interface is looped back from receive to transmit DTE. If no errors, the local user should receive data correctly.

### Local HDSL Loopback [2]

The UAS 711-D2 is capable of looping data received from the HDSL line back to the DTE as close to the HDSL line as practical. This loopback is only available if the loops are handshaking in normal operation.

### Remote Digital Loopback [3]


You may initiate a remote digital loopback. The loopback command to the remote unit is done via the EOC (Embedded Operations Channel).

### V.54 Remote Digital Loopback [4]

V.54 remote digital loopback is achieved by the initiating unit sending the V.54 preparatory pattern. Once the remote has acknowledged, the loopback is activated and data should be error free.

**Figure 4-2** Loopback Signal Paths

[Figure 4-3](#) shows a typical loopback setting screen for an HDSL system using a DTE interface.



**Figure 4-3** Loopback Screen

## Operation

To access the Loopback function, select item 1 on the Maintenance menu.

To change the state of a loopback, use the following procedure:

1. Type the number of the line of the desired loopback. This toggles the selected loopback ON and OFF.
2. To exit and return to the Maintenance menu, press the Esc key.

## Line Loopback

The local line loopback is generally used to test the connections between the local equipment and the HDSL system module.

When the local line loopback is connected (ON) (loopback [ 1 ]), the data signal received from the local user via the transmit line of the user equipment interface is returned by the HDSL system module on the receive line of that interface. Therefore, during normal operation the local user equipment should receive its own signal without errors.

The local user transmit signal is transparent and therefore is sent to the remote HDSL system; however, the signal received from the remote HDSL system is lost.

The local user transmit signal is transparent and therefore sent to the remote HDSL system, however the signal received from the remote HDSL system is lost.

## Remote Digital Loopback

The remote digital loopback is generally used to test end-to-end the proper operation of the HDSL link, and therefore should be initiated by the LTU only and used after normal operation is obtained.

When the remote digital loopback is connected (ON) (Loopback [4]), the data received by the remote module from the local user is returned by the HDSL system module on the transmit path, back to the local unit. Therefore, during normal operation the local user equipment should receive its own signal without errors.

The local user transmit signal is also passed to the remote user equipment connected to the HDSL system, however the signal transmitted by the remote user is lost.

## V.54 Remote Loopback

The V.54 remote loopback is generally used to test the proper operation of one remote to another. You should use it after normal operation is obtained. When the V.54 loopback is selected (loopback 5), the initiating unit sends the V.54 inband code to the other remote unit. Upon receiving an acknowledgment the initiating unit turns its TM LED ON indicating the far-end unit is in the loopback mode.

When the loopback is engaged, you see error -free data returning. The other remote unit data are blocked.

In the case when the other unit doesn't acknowledge the V.54 inband loopback code, or fails to transmit the acknowledgment, the initiating unit continues sending V.54 inband code and blocks data until there is a correct acknowledgment, or the loopback command is terminated.

## Test Loopbacks - Considerations

Test loopbacks are designed to allow systematic testing of the signal paths along the link, starting from one end of the link (the "local" HDSL module). In most situations, initiate the loopbacks from the side serving as the LTU, because this allows you to follow the signal path starting from the central office and continue toward the end user in addition to maintaining system timing. All of the test loopbacks are transparent.

Recommended order of test activation is as follows:

1. Line loopback.
2. HDSL local loopback.
3. Remote digital loopback
4. V.54 remote digital loopback.

This is also the order in which the loopbacks are listed on the LOOPBACKS screen.

## BER Test

This screen is used to perform bit error measurements on an HDSL system module.

### Testing Method

BER testing is performed by repeatedly transmitting a pseudo test sequence having a length of

$2^{15} - 1$  bits, and comparing by means of an error detector the received sequence. Any difference is assumed to be an error and is counted. To perform a meaningful comparison, the error counting is inhibited until the error detector becomes synchronized to the incoming sequence. During this synchronization, it is possible to see a burst of 255 errors.


During this testing, your traffic is disconnected. BER tests may be performed in an end-to-end mode that requires both LTU and NTU BER testers to be on. If testing is initiated at one end, a loopback along the signal path needs to be connected. The loopback can be a physical connection made somewhere along the signal path or a test loopback activated at the desired location as described in the loopback descriptions in this chapter. Alternatively, an external BERT may be connected to the remote unit to facilitate testing.

The measurement is carried out over discrete intervals (an interval corresponds to the time required for a transmission block of  $2^{24}$  bits). The number of errors that are displayed in each interval can be up to 255. If the actual number of errors in a given interval is higher, this maximum count is considered in the calculation of the BER. The calculated BER is updated at the end of each interval.

The bit error rate test must be done over all active individual HDSL loops simultaneously.


BER testing can be performed through the Network Manager or supervisory terminal port. The front panel LED TM is on when the BER test is initiated. When the error detection is in sync and detects no errors, the TM LED is on. But when the error detector is not in sync or detects errors, the TM blinks.

## Test Configuration Notes




### Master Self-Test:

Enable master BER test. Be sure you have an external loopback or test equipment at the remote unit to facilitate this test.




### Remote Self-Test:

Enable remote BER test. Be sure you have an external loopback or test equipment at the master unit to facilitate this test.




### Self-Test with Remote Loopback:

From master unit, assert Remote Loopback (RL) and enable BER test.



### Master to Remote Self-Test:

Enable BER test on both master and remote units.




### Remote Self-Test with V.54 RDL:

Place far-end remote 2 into Remote Loopback by sending V.54 code and turn on the self-test on that remote 1. This test can be initiated only from the front panel or supervisory terminal. Both remote units must be UAS 711-D2 or 731-D2 type units.

## BER Screen Description

A typical screen for BER testing is shown in [Figure 4-4](#).



**Figure 4-4** BER Test Screen

The dialog box used to control BER testing has two areas:

- The top area displays BER results.
- The bottom area is used to select the desired HDLSL loop you want to perform the test on, and to start and stop BER measurement.

The fields of the BER Test dialog box are described in [Table 4-1](#).

**Table 4-1** BER Test Screen Fields

Status	Displays the current status of the error detector: Sync - The error detector is synchronized, and the BER measurement is possible. Out-of-Sync - The error detector is not synchronized, and BER measurement is inhibited.
Intervals	Displays the number of measurement intervals up to this point.
BER	Displays the BER calculated up to this point.
Loopback	Displays the current state of the loopback activated for the purpose of the BER test: None- No loopback has been activated. In this case, an external loopback, e.g., a physical loopback connection, must be connected before starting the BER test. Remote Local - Remote Digital Loopback is activated for the BER test. HDLSL line loopback can also be initiated with a BER test.
Execution	Displays the next state of BER measurement: Press the SPACEBAR to start - BER measurement disabled. Press the SPACEBAR to stop - BER measurement enabled.
Reset BER	Press the spacebar to reset the BER counter.

### Operation

1. To display the BER TEST screen, select item 2 on the Maintenance menu.
2. Make sure a loopback is activated. If the Loopback field displays None and no external loopback is currently connected, change the state of the loopback used for BER measurement. Move the selection block to the Loopback line and press the spacebar.

To enable/disable BER testing:

1. To start the BER measurement, move the selection block to the Execution field and press the space bar. The Execution field now shows Stop.
2. To stop the BER measurement, move the selection block to the Execution line and press the spacebar. The Execution field now shows press SPACEBAR to start.

To exit and return to the Maintenance menu, make sure that BER testing has been disabled, and press ESC.

---

### Note

*You cannot exit the BER TEST screen while a BER test is running.*


*When you start or stop the BER test on one of the HDSL loops, the other loop(s) see bursted errors on its data.*

*The BER test detector synchronizes and shows error-free for all 1's and all 0's pattern.*

---

## Set RTC

The Set RTC option enables you to set the real-time clock of the UAS 711-D2. A typical screen is shown in [Figure 4-5](#).



**Figure 4-5** Set RTC Screen

The screen includes two fields described in [Table 4-2](#).

**Table 4-2** Set RTC Screen Fields

Time	Displays the time in 24-hr military format showing hours:minutes:seconds retrieved from the UAS 711-D2 at the time the screen is opened.
Date	Displays the date (day/month/year) retrieved from the UAS 711-D2 at the time the screen is opened.

### Operation

To change the current time or date, use the following procedure:

1. Move the selection block to the desired line and press **Enter**.
2. Type the new time or date in the format seen on the screen, then press **Enter**. The option menu closes, and the new time and/or date appears in the corresponding line.
3. To save changes, press **Ctrl W**.
4. To quit and cancel the changes made in this screen, press **Esc** without pressing **Ctrl W**.
5. To exit and return to the **Maintenance** menu, press **Esc**.

#### Note

The UAS 711-D2 internal time is updated at the instant you press **CTRL-W**.



## Reset Statistic

The `Reset Statistics` option resets all the performance statistics entries of the UAS 711-D2.

### Operation

To instruct the UAS 711-D2 to reset all the performance statistics counters:

1. Select item `4` on the `Maintenance` menu. You see a dialog box with two options: `Yes` and `No`.
2. To reset the statistics, move the selection block to `Yes`, and press `Enter`.
3. To exit without resetting press `Esc`, or move the selection block to `No`, and press `Enter`.

## HDSL Start-Up

This option is used to manually initiate the UAS 711-D2 HDSL loops start-up process. Normally this process is automatically performed upon link initialization and whenever the synchronization between two linked UAS 711-D2 units is lost.

---

**Important** *Activation of this function disrupts the transfer of data through the link for a short time*

---

To instruct the UAS 711-D2 to perform the start-up process, select item `5` on the `Maintenance` menu.

## Board Reset

This option is used to reset the UAS 711-D2.

To reset the UAS 711-D2, select item `6` on the `Maintenance` menu. After a few seconds, the opening screen appears. The unit performs the start-up process, and displays the `Main Menu`.

---

**Important** *Activation of this function disrupts the transfer of data through the link for a short time*

---



# Chapter 5: Application Guide

## Overview


This chapter includes timing notes and typical applications to assist you in configuring your system.

## Timing Options

### High Channel Data Rate Application

The length of the cable connecting your equipment (the DTE) to the UAS 711-D2 is an important factor when using internal or looped timing in a high data rate application. (With internal or looped timing, the UAS 711-D2 provides timing to the DTE.) The cable creates a delay between the UAS 711-D2 clock and data arriving from the DTE. When this delay is too great (because the cable is too long or the rate is too high), it can cause errors.

If errors occur with DCE timing, you can use external timing for the LTU UAS 711-D2 and loop timing for the NTU UAS 711-D2. This permits operation at any data rate, regardless of cable length. (Note that the ITU-T V.35 recommendation limits cable length to about 30 m.) Refer to [Figure 5-1](#) and *Chapter 3 - Operation* for configuring timing options.



**Figure 5-1** UAS 711-D2 System Timing

## Typical Applications

[Figure 5-2](#) through [Figure 5-4](#) show typical applications and option settings for configuring your system for passing data.


### Single Loop Point-to-Point



Option/Setting			
711-D2			731-D2
NTU/LTU (Unit Type)	LTU	NTU	LTU/NTU
NLP0/NLP1 (Enable Loops)	1	1	1
CCK0/CCK1 (Tx Clock Mode)	External	Looped	Looped
CTS0/CTS1 (CTS Mode)	On	On	On
CKS1-CKS6 (Data Rate)	12x64 kbps	12x64 kbps	12x64 kbps

**Figure 5-2** Single Loop Point-to-Point Application


### Two Loop Point-to-Point



Option/Setting			
711-D2			731-D2
NTU/LTU (Unit Type)	LTU	NTU	LTU/NTU
NLP0/NLP1 (Enable Loops)	2	2	2
CCK0/CCK1 (Tx Clock Mode)	External	Looped	Looped
CTS0/CTS1 (CTS Mode)	On	On	On
CKS1-CKS6 (Data Rate)	24x64 kbps	24x64 kbps	24x64 kbps

**Figure 5-3** Two Loop Point-to-Point Application

## Fractional T1 Service (2 Loop)



Option/Setting				
711-D2			701-T2	721-T2
NTU/LTU (Unit Type)	LTU	NTU	LTU/NTU	LTU/NTU
NLP0/NLP1 (Enable Loops)	2	2	2	2
CCK0/CCK1 (Tx Clock Mode)	External	Looped	Looped	Looped
CTS0/CTS1 (CTS Mode)	On	On	Not Applicable	Not Applicable
CKS1-CKS6 (Data Rate)	1x64 kbps to 24x64 kbps	1x64 kbps to 24x64 kbps	24x64 kbps	24x64 kbps
Note: When optioning a Fractional Service less than 1.536 Mbps (24x64 kbps) the Network Configuring Screen is used to determine the loop bandwidth.				

**Figure 5-4** Fractional T1 Service (2-Loop) Application



# Appendix A: Technical Characteristics

**Table A-1** Technical Characteristics

DTE Interface	
Rate	N x 64 kbps, N = 1 to 24
Interface	V.35 [optional X.21 or V.11 (530)]
HDSL Interface	
Rate	Dual duplex 32 kbaud signaling rate, with <b>2B1Q*</b> line code (each loop)
Framing	HDSL framing per ETSI DTR/TM 3017, including performance monitoring via HDSL CRC indication
Transmit Power	13.5 dBm ( $\pm 0.5$ dB)
Transmission Line	
Two non-loaded metallic twisted-pairs (loop # 1 and loop # 2), up to 12 km on 26 AWG under the following conditions: No loading coils, no additional shielding. When Bridged-Taps (BTs) are present, the following rules apply: Maximum number of bridged-taps = 2 Maximum tap length = 1000 meters No loop impairments Meets performance specification of T1E1.4 Technical Report #28, Bellcore TA-NWT-1210.	
Test Features	
Line Loopback Remote Digital Loopback V.54 Remote Digital Loopback Self Tests: PRBS Generator and BER Meter	Terminal screen selectable. Terminal screen selectable. Terminal screen selectable. Terminal screen selectable. Terminal screen selectable
*2B1Q: Line code for basic rate ISDN at the U reference point. 2B1Q (2 Binary 1 Quaternary) is a line encoding format that is supported on 2-wire interfaces.	

## Technical Characteristics

**Table A-1** Technical Characteristics (Cont.)

Dimensions	
Height	27 mm (0.8 in.)
Width	178 mm (7.0 in.)
Depth	241 mm (9.5 in.)
Weight	0.28 kg (10.0 oz.)
Shipping Weight	0.74 kg (1.0 lbs, 10 oz.)
Temperature	0° to 50°C (32° to 122°F) operating –40° to 85°C (–40° to 158°F) non-operating
Electrical	
Power	+5 Vdc 730mA +12 Vdc 74mA –12 Vdc 94mA Load Number = 0.9
Environmental	
Temperature Card Assembly Operation Card Assembly Storage/ Non-Operating	0 to 50 degrees Celsius –40 to +85 degrees Celsius
Humidity	5 to 95% non-condensing
Altitude Operating Non-Operating	0 to 10,000 feet 0 to 40,000 feet



## Appendix B: HDSL Connector Pin Assignments

**Table B-1** HDSL Connector Pin Assignments

Connector Pin Assignments HDSL Connector		
Pin No.	RJ48C/X	Color
1	HDSL2-R	Blue
2	HDSL2-T	Orange
3		Black
4	HDSL1-R	Red
5	HDSL1-T	Green
6		Yellow
7		Brown
8		Slate



Lower jacks  
J33 to J48  
(HDSL Connectors)

## HDSL Connector Pin Assignments

# Appendix C: Business Equipment (DTE)

**Table C-1** ITU-T V.35

V.35					
Zone 3 DB-25 Pin	V.35 Pin	ITU-T (See Note)	EIA	Signal	Description
1	A	101	AA	Protective ground	This circuit is connected to the equipment frame. Normally, it is separated from signal ground (pin B) by 100 ohms, but it may be connected to signal ground by means of an option strap.
7	B	102	AB	Signal ground	Establishes a common ground reference for all interface circuits except protective ground, pin A.
4	C	105	CA	Request-to-send	Indicates to 711 that DTE is prepared to transmit.
5	D	106	CB	Clear-to-send	Indicates to DTE that 711 is prepared to transmit.
6	E	107	CC	Data-set-ready	Indicates to DTE that 711 is operational.
8	F	109	CF	Received line signal detector	Indicates to DTE that 711 is receiving data (not idle or OOS codes).
25	NN	142	TM	Test mode	Indicates to DTE that 711 in a test mode.
18	L	141	LL	Line loopback enable	Transfers signal from DTE to control Line Loopback test mode.
2 14	P S	103 103	BA(A) BA(B)	Transmitted data	Transfers data signals from DTE for modulation and transmission over communications line.
3 16	R T	104 104	BB(A) BB(B)	Received data	Transfers data signals received over communication line and demodulated by 711 to DTE.
24 11	U W	113 113	DA(A) DA(B)	Transmitter timing (DTE source)	Transfers transmitter signal timing information from DTE to 711.
17 9	V X	115 115	DD(A) DD(B)	Receiver timing	Transfers receiver signal timing information from 711 to DTE.
15 12	Y AA	114 114	DB(A) DB(B)	Transmitter timing	Transfers transmitter signal timing information from 711 to DTE.
21	BB/b	140	RL	Remote Digital Loopback test enable	Transfers signal from DTE to control Remote Digital Loopback test mode.
20	H	108/2	CD	Data Terminal Ready	Indicates to 711 that DTE is prepared for data communication.
<b>NOTE:</b> ITU-T designations are shown for reference only. Since Zone 3 DB-12 Pin is an external connector, Zone 3 DB-25 connector of the shelf maps to V.35 pin via cable adapter 027H572-001 (DB-25M to V.35).					

**Table C-2** EIA-530

EIA-530			
Zone 3 DB-25 Pin	Circuit	Direction	Description
1			Frame Ground
2	BA	To 711	Send Data (A)
14	BA	To 711	Send Data (B)
3	BB	From 711	RCV Data (A)
16	BB	From 711	RCV Data (B)
4	CA	To 711	RTS (A)
19	CA	To 711	RTS (B)
5	CB	From 711	CTS (A)
13	CB	From 711	CTS (B)
6	CC	From 711	DSR (A)
22	CC	From 711	DSR (B)
7	AB		Signal Ground
8	CF	From 711	DCD (A)
10	CF	From 711	DCD (B)
17	DD	From 711	RCV CLK (A)
9	DD	From 711	RCV CLK (B)
24	DA	To 711	EXT CLK (A)
11	DA	To 711	EXT CLK (B)
15	DB	From 711	TX CLK (A)
12	DB	From 711	TX CLK (B)
20	CD	To 711	DTR (A)
23	CD	To 711	DTR (B)
21	RL	To 711	Remote Digital Loopback Enable
18	LL	To 711	Line Loopback Enable
25	TM	From 711	Test Mode

**Table C-3** X.21

X.21				
Zone 3 DB-25 Pin	* 15-Pin X.21 Connector	ITU-T Circuit	Signal	Description
2 14	2 9	T(A) T(B)	Transmitted Data	Data from DTE.
3 16	4 11	R(A) R(B)	Received Data	Data to DTE.
4 19	3 10	C(A) C(B)	Control	Indicates to 711 that DTE is prepared to transmit.
8 10	5 12	I(A) I(B)	Indication	Indicates to DTE that 711 is receiving data.
17 9	6 13	S(A) S(B)	Signal Element Timing	Transmit and receive signal timing information from 711 to DTE.
24 12	7 14	X(A) X(B)	* DTE Signal Element Timing (X)	Optional transmit signal timing information from DTE to 711 if X.21 adapter module is configured for XT.
7	8	G	Signal Ground	Common ground reference.
* Optional transmit signal timing, X.21 Interface Card jumper position BT, (Byte Timing) is not supported.				



# Glossary of Terms

---

## 2B1Q

Line code for basic rate ISDN at the U reference point. 2B1Q (2 Binary 1 Quaternary) is a line encoding format that is supported on 2-wire interfaces.

---

## A

### Address

A sequence of bits, a character, or a group of characters that identifies a network station, user, or application; used mainly for routing purposes.

---

## B

### BERT

Bit Error Rate Test, or tester. (See Bit Error Rate.)

### Bit Error Rate (BER)

The percentage of received bits that are in error, relative to a specific amount of bits received; usually expressed as a number referenced to a power of 10; e.g., 1 in  $10^5$ .

---

## D

### Data Set Ready (DSR)

The data set is ready to accept data.

### Diagnostics

Tests used to detect malfunctions in a system or component.

### Digital Loopback (DL)

Technique for testing the digital processing circuitry of a communications device; may be initiated locally or remotely via a telecommunications circuit; device being tested echoes back a received test message, after first decoding and then reencoding it, the results of which are compared with the original message.

### DTE

Data Termination Equipment

---

### E

#### E1

European telecommunications standard defined by CCITT standards G.703, G.704, and G.732.

#### HDSL

High-Bit-Rate Digital Subscriber Line.

---

### L

#### Loopback

Diagnostic procedure used for transmission devices; a test message is sent to a device being tested, which is then sent back to the originator and compared with the original transmission; loopback testing may be within a locally attached device or conducted remotely over a communications circuit.

#### LTU

Line Terminating Unit

---

### N

#### Network

An interconnected group of nodes; a series of points, nodes, or stations connected by communications channels; the assembly of equipment through which connections are made between data stations.

#### Node

Any addressable location within a network capable of carrying a circuit.

#### NTU

Network Terminating Unit

---

### S

#### Self-Test

A diagnostic test mode to check modem performance in which the modem is disconnected from the telephone facility and its transmitter's output is connected to its receiver's input, permitting the looping of test messages (originated by the modem test circuitry) through the modem.

#### Simple Network Management Protocol (SNMP)

A request-response type of protocol that gathers management information from network devices. A de facto standard protocol for network management.

#### SpectraComm Manager (SCM)

A printed circuit card that is an SNMP proxy agent for network elements colocated with it in a SpectraComm Shelf and for remote network elements that communicate with them.



---

## T

### Terminal

A point in a network at which data can either enter or leave; a device, usually equipped with a keyboard, often with a display, capable of sending and receiving data over a communications link (IBM).

### Transmission

The dispatching of a signal, message, or other form of intelligence by wire, radio, telegraphy, telephony, facsimile, or other means (ISO); a series of characters, messages or blocks, including control information and user data; the signaling of data over communications channels.

---

## U

### Universal Access System (UAS)

The UAS is a family of network managed metallic loop transmission products. UAS is also used to represent **Unavailable Seconds**.



# INDEX

## A

Acronyms G-1  
Applications 1-2

## B

BER Screen Description 4-8  
BER Test 4-6  
Board Reset 4-11

## C

Cancel Startup 3-10  
Communications Line 2-7  
Configuration 3-6  
Configuration Menu 3-11  
Conventions  
    Typographical P-2

## D

Diagnostic Menu 3-7  
Diagnostics 3-6  
Diagnostics/Network Management 1-2

## E

EIA-530 or X.21 Interface Card 2-6  
Equipment List 1-3

## F

Features 1-1  
Field Editing 3-4  
Field Navigation 3-4  
Fractional G.704 Service (2 Loop) 5-3  
Fractional T1 Service 1-2  
Front Panel 3-2

## G

GDC  
    Publications P-1  
Glossary G-1

## H

HDSL Monitoring 3-7  
HDSL Start-Up 4-11

HDSL Status 3-9  
High Channel Data Rate Application 5-1

## I

Installation 2-1  
Installation of Shelf 2-1  
Installing the DIU 7626 2-6  
Interface Configuration Screen 3-13

## L

Line Loopback 4-4  
Loopback Screen 4-4  
Loopback Signal Paths 4-3  
Loopback Testing 4-3

## M

Main Menu 3-5  
Maintenance 3-6  
Maintenance Menu 3-16  
Manuals P-1  
Menu Selection 3-4  
MIB Tables 3-16

## N

Network Management 3-16

## O

Operating Procedures 3-4  
Options 2-6  
Overview 1-1

## P

Point-to-Point 1-2  
Power Line 2-6  
Preoperational Configuration Setup 2-8  
Publications P-1

## Q

Quitting Without Saving 3-5

## R

Rear Panel Shelf Cabling 2-7

## **Index**

Refresh 3-5

Remote Digital Loopback 4-5

Reset Statistic 4-11

Restoring Default Values 3-5

### **S**

Saving Values 3-5

Screen Organization 3-3

Set RTC 4-10

Setting Hard Options 2-1

Single Loop Point-to-Point 5-2

Soft Configuration and Control 3-2

Startup Procedure 3-3

### **T**

T! Service Provisioning Options 3-14

Technical Characteristics A-1

Terminal Requirements 3-2

Test Configuration Notes 4-7

Test Loopbacks - Considerations 4-6

Testing Method 4-6

Timing Options 5-1

Troubleshooting 4-1

Two Loop Point-to-Point 5-2

Typical Applications 5-2

### **U**

UAS 711-D2 System Timing 5-1

Unit Configuration Screen 3-12

Unpacking and Handling 2-1


### **V**

V.54 Remote Loopback 4-5

View H/S Configuration 3-15

View H/S Configuration Screen 3-15





**General DataComm**